

FOAM BACK INSTALLATION

A 24 Hour Relaxation Period is recommended before gluing down turf to prevent shrinking and for expanding after glue down. IDEAL temperatures should be above 70 degrees.

When Turf is Delivered: Check its texture, color, and style; make sure there are no visible defects *before* installation. We recommend using a polyurethane compatible seam sealer.

Floor Preparation (when not using seaming tape)

- **Temperature and Humidity-**

The environment in which the turf is to be installed must be controlled with the temperature between 65° F and 95° F (18° C and 35° C) and the relative humidity between 10% and 65%. If installing over concrete, the slab temperature should not be less than 65° F (18° C). These conditions must be maintained for at least 48 hours before, during, and 48 hours after the installation.

Floor Preparation - Each subfloor shall be inspected to determine the special care required to make it a suitable foundation for turf. **All** cracks 1/8 inch (3 mm) wide or protrusions over 1/32 inch (.8 mm) should be filled or leveled.

- **Concrete**

Concrete shall be cured, clean, and dry. If the turf is to be installed using an adhesive, the concrete shall be free of paint, dirt, grease, oil, curing or parting agents, and other contaminants, including sealers, that may interfere with the bonding of the adhesive. Whenever a powdery or porous surface is encountered, a primer compatible with the adhesive shall be used to provide a suitable surface for the glue-down installation. Patching of cracks and depressions shall be made with an appropriate and compatible latex or polymer fortified patching compound. Do not exceed manufacturer's recommendations for patch thickness. Large patched areas must be primed.

Moisture Testing (when not using seaming tape)

Concrete floors, even with adequate curing time, can present an unacceptable moisture condition by allowing excessive amounts of moisture vapor to pass through to the surface. This can be a problem even on suspended concrete floors. All concrete floors should be tested for moisture emission rate by utilizing an anhydrous calcium chloride moisture test kit available from installation supplies and accessories distributors. This quantitative method is very precise and must be conducted carefully, with strict attention to the test kit manufacturer's detailed instructions. Moisture emission rate is expressed in lbs/1000 sq ft/24 hours.

Because the calcium chloride test for emission rate requires 3 days to conduct, proper installation planning is a must.

As a general guideline, an emission rate of 3 lbs (1.4 kg) or less is acceptable for most turf. In the range from 3 lbs to 5 lbs (1.4 to 2.3 kg), carpet with porous backings can usually be installed successfully; but the risk of moisture-related problems increases. Since some floor covering products are less tolerant of moisture than others, always consult the individual manufacturer to determine the emission rate for specific products

Get glue approval before starting {see bottom for list}

Trimming Selvedge (edge seam)

- Trim the turf **Face up!** You will not be able to follow the stitch rows if you trim or cut face down. When splitting the roll “bloom” the fibers where the cut is needed by running an T-Handle Tool between the stitch rows, once the fibers are “bloomed” then using a Slide knife follow the area (between the stitch rows) for an accurate cut to maintain the gauge.
- **FACTORY PRE-TRIM AVAILABLE, CALL FOR PRICING**

Turf Laying Techniques

- Start in middle of room using chalk line
- Butt turf together SQUARE at center line
- Place weight (anything over 30 pounds every 5-10 feet) starting seven feet off center line in both directions
- CAUTION, do not forcefully move turf when folding/unfolding, be careful as to keep turf square to the center line, and adjoining turf
- A 100% glue down turf is recommended. Procedures issued by the adhesive manufacturer should be followed. For best results use a *Seam Sealer* to prevent heavy wear on the seam. Ask sales rep for directions
- Roll turf with 100 pound roller until glue tacks up.

100% GLUE DOWN AND SEAM SEALER RECOMMENDED FOR HEAVY TRAFFIC

Approved Adhesives

Turf Claw Adhesive (5 Gallons)

- TurfClaw 75

Turf Claw Foam Back (4 Gallons)

- TurfClaw FB (not to be used to adhere seam tape)